

Cover fleece Manual & Safety warning

Product Description

- **Product Name:** Cover Fleece
 - **Article numbers:** 21050, 21010, 21015
 - **Weight:** 200 GSM
 - **Type:** Floor protector and cover fleece
 - **Suitable for:** Hard and smooth floors such as laminate, PVC, tiles, and plastic floors
 - **Features:** Liquid-tight, reusable, easy to remove
-

Key Features

1. **Liquid-tight:** Protects floors from moisture, dirt and paint.
 2. **Versatile:** Suitable for various applications during construction, renovation and painting work.
 3. **Reusable:** Clean, fold and reuse Cover Fleece for your next project.
 4. **Easy removal:** Leaves no adhesive residue, keeping the floor clean.
-

Manual

Preparation

1. **Surface cleaning:** Ensure that the floor is dry, dust-free and clean to ensure an optimal position of the cover fleece.
2. **Switching off underfloor heating:** Make sure that the underfloor heating is completely switched off before applying the cover fleece.

Installation

1. **Roll out:** Start on one side of the room and roll out the cover fleece with the non-slip side facing down.
2. **Overlap:** Let the strips overlap by at least 10 cm for full coverage.
3. **Mapping:** Tape the fleece well with tape where necessary.
4. **Check:** Check that the fleece is securely attached and does not move during use.

Removal

1. **After use:** Gently lift the cover fleece, starting at an edge, and fold it carefully.
2. **Residue-free removal:** Check the floor for any residue left behind and remove it with a soft cloth if necessary.
3. **Store for reuse:** Clean the fleece if necessary, fold it up, and store it in a dry place for future use.
4. **Waste:** After last use, the fleece must be disposed of with the residual waste.

Safety Warnings

1. **Not suitable for all surfaces:** Do not use the cover fleece on freshly laid floors, porous stones, natural stone floors, clay tiles or recently poured concrete. Always test on a small, inconspicuous area of the floor first.
2. **Limit the duration of use:** Use the cover fleece for a maximum of 3 months to prevent damage to the floor.
3. **Temperature limitations:** Make sure the processing temperature is between 5°C and 40°C. Use outside of these limits may affect performance.
4. **Do not use with underfloor heating:** Make sure the underfloor heating is turned off to avoid the risk of damage to the fleece.
5. **Caution with sharp objects:** Avoid using sharp tools or heavy equipment on the fleece to avoid tearing or damage.
6. **Children and pets:** Keep the roll and packaging out of reach of children and pets to avoid the risk of choking.

Maintenance and Storage

- **Cleaning:** Remove dust, dirt, or spills from the fleece after use with a soft cloth.
 - **Storage:** Store unused rolls in a cool, dry place away from direct sunlight and extreme temperatures.
 - **Reuse:** Check the fleece for tears or wear before using it again.
-

Important Notes

- Always test the cover fleece on a small surface before applying it completely.
 - Replace damaged fleece immediately to ensure floor protection.
-

Cover fleece offers a high-quality solution for floor protection during construction and renovation work. Follow this guide for safe and effective use. Contact the vendor for questions or support.