

Floor cover Manual & Safety Warning

Product Description

- **Product Name**: Floor cover Nonwoven
- Article numbers: 24060
- Thickness: 60 µm
- Type: Self-adhesive floor protector and cover fleece
- Suitable for: Hard floors
- Features: Liquid-tight, reusable, easy to remove

Key Features

- 1. Liquid-tight: Protects floors from moisture, dirt and paint.
- 2. **Self-adhesive convenience**: No extra tape needed, easy to apply and firmly attached.
- 3. **Versatile**: Suitable for various applications during construction, renovation and painting work.
- 4. **Easy removal**: Leaves no adhesive residue, keeping the floor clean.

Manual

Preparation

- 1. **Clean the surface**: Ensure that the floor is dry, dust-free and clean to ensure optimal adhesion of the cover fleece.
- 2. **Switching off underfloor heating**: Make sure that the underfloor heating is completely switched off before applying the cover fleece.



Installation

- 1. **Roll out**: Start on one side of the room and roll out the cover fleece with the adhesive side facing down.
- 2. **Press:** Press the membrane firmly with your hands or a flat tool to remove air bubbles and folds.
- 3. **Overlap:** Let the strips overlap by at least 10 cm for full coverage.
- 4. **Check**: Check that the fleece is securely attached and does not move during use.

Removal

- 1. After use: Gently lift the cover fleece, starting at an edge, and slowly peel it off.
- 2. **Residue-free removal**: Check the floor for any remaining residue and remove it with a soft cloth if necessary.
- 3. **Store for reuse**: Clean the fleece if necessary, fold it up, and store it in a dry place for future use.
- 4. **Waste**: After last use, the fleece must be disposed of with the residual waste.

Safety Warnings

- 1. Not suitable for all surfaces: Do not use the cover fleece on freshly laid floors or recently poured concrete. Always test on a small, inconspicuous area of the floor first.
- 2. **Limit the duration of use**: Use the cover fleece for a maximum of 60 days to ensure UV protection.
- 3. **Temperature limitations**: Make sure the processing temperature is between 10°C and 25°C. Use outside of these limits may affect performance.
- 4. **Do not use with underfloor heating**: Make sure the underfloor heating is turned off to avoid the risk of adhesive residue or damage to the fleece.
- 5. **Caution with sharp objects**: Avoid using sharp tools or heavy equipment on the fleece to avoid tearing or damage.
- 6. **Children and pets**: Keep the roll and packaging out of reach of children and pets to avoid the risk of choking.



Maintenance and Storage

- **Cleaning**: Remove dust, dirt, or spills from the fleece after use with a soft cloth.
- **Storage**: Store unused rolls in a cool, dry place away from direct sunlight and extreme temperatures.
- **Reuse**: Check the fleece for tears or wear before using it again.

Important Notes

- Always test the cover fleece on a small surface before applying it completely.
- Replace damaged fleece immediately to ensure floor protection.

Floorcover Fleece offers a high-quality solution for floor protection during construction and renovation work. Follow this guide for safe and effective use. Contact the vendor for questions or support.